

8" x 8' TUBE

SIMPLE APPLICATION FOR SLOPES

1



DIG

Dig a 2" to 3" deep by 9" wide trench along the bottom of the slope.

2



SET

Place straw wattle in dug trench. Compact leftover soil from the excavated trench against wattle on uphill side.

3



STAKE

Stake wattle to ground using 18"-24" 1"X1" wooden stakes. Space 3'-4' between stakes, leaving 2"-3" of stake above wattle.

Stakes not included