

NO MIXING

FAST ACTING

Simply spray on and hose off
No Pressure Washing needed

30 SECONDS[®]
The Original Since 1977

OUTDOOR CLEANER

[®]

READY TO USE

SAFE

around your yard
plants & lawn



Includes

Motorized Power Sprayer

1.3 Gallon / 5 Liters


Cleans Stains From

ALGAE, MOLD & MILDEW

When used as directed

KEEP OUT OF REACH OF CHILDREN. WARNING: See adjacent panel for other cautions. Reverso in español


DECKS, COMPOSITE
& STAINED SURFACES



CONCRETE, BRICKS
& MASONRY



GUTTERS, SIDING,
CANVAS, PLASTIC
& STUCCO



FENCES, ARBORS
& PAINTED SURFACES



30SECONDS[®]

The Original Since 1977

OUTDOOR CLEANER[®]

Cleans Stains From
ALGAE, MOLD, & MILDEW

CLEANS: Awnings • Birdbaths • Bricks • Boats • Concrete • Decks • Fences • Fiberglass • Flowerpots • Garden Décor • Gutters • Lanais • Mailboxes • Outdoor Furniture & Canvas • Painted Surfaces • Patios • Planter Boxes • Porches • RV Tops • Stepping Stones • Stucco • Tarps • Tents • Tiles • Vinyl Fencing & Siding • Wood...

DIRECTIONS: Ready To Use, Ready To Go



1. Attach Motorized Power Sprayer to bottle



2. On a DRY surface saturate with product



3. Rinse with a garden hose

METAL, PLASTIC, CLOTH, PAINTED SURFACES, FIBERGLASS

Keep wet with the product for up to **3 MINUTES**, then brush surface if necessary. (Non-Corrosive to metals when used as directed.)

WOOD, COMPOSITE

Keep wet with the product for up to **5 MINUTES**, then brush surface with the grain. (Stained wood can become blotchy in appearance. This is remedied by re-staining.)

CONCRETE, MASONRY, TILE, ASPHALT

Keep wet with the product for up to **15 MINUTES**, then brush if necessary. (Non-staining to concrete.)

For heavier stains, reapply cleaner to surface before rinsing and brush again, if necessary. Rinse the surface thoroughly using a garden hose. After each use, clean applicator thoroughly with water.

COVERAGE:

Product will clean up to 400 sq.ft. depending on the amount of staining and porosity of the surface to be cleaned.

PRECAUTIONS:

Store **30 SECONDS OUTDOOR CLEANER** in a cool, dark place and transport in an upright position. Always test an inconspicuous area on surfaces that are susceptible to corrosive, dulling and bleaching effects. For example: fabric, color paving, high gloss paint and untreated metals. Wear old clothing. **30 SECONDS** will discolor clothes. Rinse plant foliage and metals, within 10 minutes of application. Do not let **30 SECONDS** dry on glass.

CAUTIONS:

Keep out of reach of children. Use in a ventilated area. Do not mix with other household chemicals. In case of eye or skin contact, flush immediately with water for at least 15 minutes. Seek medical attention if irritation persists. If swallowed, drink plenty of water, do not induce vomiting and call physician immediately. Do not allow **30 SECONDS** to enter lakes or streams.

CONTENTS:

Sodium Hypochlorite (bleach) Commercial grade, highly stable, 70% less NaCl.....2.5%
Proprietary ingredients.....0.6%
Inert ingredients.....96.9%



MADE in the USA

COLLIER Manufacturing, LLC
Troutdale, OR • 97060 USA
☎ 503-669-1953



Real results from real customers / Resultados reales de clientes reales

www.30SECONDSCleaners.com

PELAR
AQUI

30SECONDS[®]

The Original Since 1977

OUTDOOR CLEANER[®] Limpia las manchas de **ALGAS, HONGOS y MOHO**

LIMPIA: Toldos, Fuentes para Pájaros, Ladrillo, Botes, Concreto, Cubiertas, Vallas, Fibra de Vidrio, Floreros, Decoraciones de Jardín, Canaletas, Terrazas Techadas, Buzones, Muebles y Lonas de Exterior, Superficies Pintadas, Patios, Jardineras, Porches, Techos de Casas Rodantes, Caminos de Piedra, Estucados, Lonas, Tiendas de Campaña, Azulejos, Vallas y Revestimientos de Vinilo, Madera...

INSTRUCCIONES: Listo para Usarse, Listo para Partir



1. Acople el Rociador Eléctrico Motorizado a la botella



2. Sature una superficie SECA con el producto



3. Enjuague con una manguera de jardín

METAL, PLÁSTICO, TELA, SUPERFICIES PINTADAS, FIBRA DE VIDRIO

Mantenga húmedo con el producto hasta 3 MINUTOS, luego cepille la superficie si es necesario. (No corroe los metales si se usa según las instrucciones).

MADERA, COMPUESTO

Mantenga húmedo con el producto hasta 5 MINUTOS, luego cepille la superficie al hilo. (La madera teñida puede lucir manchada. Eso se soluciona cubriendo la mancha.)

CONCRETO, MAMPOSTERÍA, BALDOSAS, ASFALTO

Mantenga húmedo con el producto hasta 3 MINUTOS, luego cepille si es necesario. (No mancha el concreto).

En caso de que haya manchas más difíciles, aplique nuevamente el limpiador en la superficie antes de enjuagar y vuelva a cepillar si es necesario. Enjuague bien la superficie usando una manguera de jardín. Después de cada uso, limpie el aplicador profundamente con agua.

COBERTURA:

El producto limpiará hasta 400 pies cuadrados, dependiendo de qué tan manchada y que tan porosa sea la superficie a limpiar.

PRECAUCIONES:

Almacene **30 SECONDS OUTDOOR CLEANER** en un lugar fresco y protegido de la luz y téngalo en posición vertical. Siempre haga una prueba en áreas poco visibles en superficies susceptibles a los efectos corrosivos, mateantes y de decoloración. Por ejemplo: Tela, pavimento de color, pintura de alto brillo y metales sin tratar. Póngase ropa vieja. **30 SECONDS** decolora la ropa. Enjuague las hojas de las plantas y los metales dentro de los 10 minutos después de la aplicación. No permita que **30 SECONDS** se seque en el vidrio.

ADVERTENCIAS:

Mantener fuera del alcance de los niños. Usar en un área ventilada. No mezclar con otros químicos domésticos. En caso de contacto con ojos o la piel, enjuague de inmediato con agua por lo menos durante 15 minutos. Busque atención médica si persiste la irritación. En caso de ingestión, tome abundante agua, no provoque el vómito y llame al médico de inmediato. No permita que **30 SECONDS** ingrese en lagos ni arroyos.

CONTENIDOS:

Hipoclorito de Sodio (lejía) de grado comercial, altamente estable, 70% menos de NaCl.....2.5%
Ingredientes patentados0.6%
Ingredientes inerte.....96.9%

 Hecho en los Estados Unidos
www.30SECONDSCleaners.com

COLLIER Manufacturing, LLC

Troutdale, OR • 97060 USA

 503-669-1953

